


REFRIGERATOR

MODELS:

DYF42BIWS01 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	3400230	Screw	34		Bracket, Support Base (Front)
	W10539434	Use & Care Guide	16	2257644	Hinge, Top		2006616	Left Hand
	W10593343	Energy Guide	17	W10348782	Bracket, Filter		2006556	Right Hand
	2306424	Ice maker and Ingredient Care Center Service Sheet	18	W10001250	Screw	35	1157158	Screw
	2220407	Modular Ice maker Service Sheet	19	2004994	Lock, Bushing	36	2006617	Bracket, Base Support
	W10539432	Installation Instructions	20	W10484913	Bushing, Top Hinge	37	2006346	Washer, Extension Arm
2		Cabinet (Not A Serviceable Part)	21	2004514	Clip	38	2316859	Bushing, Extension Arm
3		Button, Water Filter	22	2221242	Spring, Door Closure (Green)	39	1163283	Screw
	2260503B	Black	23	486194	Screw	40	W10271541	Connector, Union
4	W10138054	Assembly, Roller	24	2005008	Retaining Ring, Adjustable Bushing	41	8281163	Screw (Stainless)
5		Support, Leveler Assembly	25	W10129069	Clip, Tube	42		Switch, Rocker Arm
	W10138423	Right Hand	26	W10482554	Cover, Bottom Gap		1118894	Switch, Rocker Arm (Refrigerator)
	W10279275	Left Hand	27		Hinge (Bottom)		1115373	Switch, Rocker Arm, Combination(Freezer)
6		Cap, Water Filter		2006780	Right Hand	43	2215938	Cover, Switch
	2260518B	Black	28	2302876	Bushing, Adjustable	44	487415	Screw
7	2307640	Mounting Bracket, Grill	29	8533913	Screw	45		Bracket, Switch
8	2307584	Grommet, Crossover Tube	30		Skirt-Grille, Bottom		2221097	Right Hand
9	2320509	Stop, Door		2209025B	Black		2221096	Left Hand
10	W10121140	Housing, Water Filter	31		Extension Arm, Door Closer	46	2215612	Cover, Air Duct
11	2318189	Tray, Filter Drip		2266882	Right Hand	47	2005032	Leveler, Adjustable
12	3400525	Screw		2266881	Left Hand	48	2314064	Tube, Drain
13	AFF6	Filter, Water	32		Grille Bottom, Front			
14	489399	Screw		2325185B	Black			
			33	W10485630	Screw			


CABINET TRIM PARTS



CABINET TRIM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cab Side (Right)	4	486194	Screw	7	W10121451	Insert, Blind Threaded
	W10132472	Aluminum	5		Trim, Top Cab	8	2005925	Seal, Side Trim
2	1163283	Screw		2314017	Aluminum	9	W10001250	Screw
3		Trim, Bottom	6		Trim, Cab Side (Left)			
	2316687	Aluminum		W10132541	Aluminum			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	10	W10169528	Assembly, Control Baffle	19	2317844	Assembly, Thermistor
2	2306010	Thermistor	11	W10237018	Release Valve	20	2188820	Thermistor
3	2208970	Air Duct	12	2310205	Assembly, Meat Pan Wire	21	W10475010	Assembly, Spacer
4	2259077	Ladder, Shelf	13	8533929	Screw (Stainless)	22	2309087	Cover, Air Diffuser
5	520965	Support, Ladder	14	486194	Screw	24	2259398	Seal, Air Duct
6	2006475	Screw (White)	15	2221296	Air Baffle Assembly			
7	487539	Screw (Stainless)	16	2327509	Reservoir, Water			
8	2302937	Thermistor Assembly	17	W10141518	Screw			
9	2302986	Lid, Baffle	18	2309222	Assembly, Air Diffuser			






FREEZER LINER AND AIR FLOW PARTS



FREEZER LINER AND AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	20		Liner (Not A Serviceable Part)	37	2006475	Screw (White)
2	2198665	Tube, Circuit Board	21	2259025	Cover, Air Outlet	38	2259032	Ladder, Shelf
3	2169142	Blade, Fan	22	2307751	Light Shield	39	2259445	Support, Ladder Screw
4	W10260421	Retainer, Fan Motor	23	W10428000	Cover, Evaporator	40	2198634	Pin, Door
5	2302817	Gasket, Cover	24	2302850	Support, Air Duct	41	W10193840	P.C. Board, Emitter
6	W10321090	Grommet, Motor	25	487539	Screw (Stainless)	42	2198633	Flipper Shut Off
7	486194	Screw	26	2198635	Spring, Door	43	2315398	Slide, Icemaker Shut Off
8	2259464	Wedge, Right Air Duct	27	2309283	Deflector, Air Duct	44	W10290817	P.C. Board Receiver
9	W10141604	Screw	28	1112260	Support, Evaporator	45	W10160570	Bi-Metal, Defrost
10	W10191429	Socket, Light	29	W10173127	Assembly, Shelf Stud	46	W10142283	Screw (White)
11	489348	Clamp, Tube	30	W10191952	Screw			
12	2326255	Bulb, Light	31		Evaporator, Cover Rail			
13	489214	Screw		2221107	Left Hand			
14	2182120	Fan Scroll		2259355	Right Hand			
15	2259465	Wedge, Left Air Duct	32	2220904	Gasket, Evaporator Cover			
16	2307774	Air Duct	33	W10151208	Cover, Receiver			
17	2198643	Lens, Receiver	34	W10482187	Harness, Bi-Metal Wire			
18		Block, Fan Scroll	35	2306010	Thermistor			
	2209480	Right Hand	36	2317105	Cover, Thermistor			
	2209066	Left Hand						
19	W10151205	Cover, Emitter						


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10395653	Ice Container Assembly	4	2198628	Seal	8	2318028	Cover
2	8281163	Screw (Stainless)	5	2318082	Drive Shaft	9	2315559	Bearing Sleeve
3	2188919	Clip, Shaft	6	2318011	Enclosure, Motor			
			7	2315547	Motor, Dispenser			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10560597	Control Box Assembly	5	2307595	Shield, Control Box	8	W10191429	Socket, Light
2	2317000	Clip, Control Box	6	487539	Screw (Stainless)	9	2326255	Bulb, Light
3	W10458299	Wire, Jumper	7	W10151210	Display Board, Ingredient Care Center	10	8281251	Screw (White)
4	2307592	Bracket, Control Box						


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10556777	Shelf Assembly	11	2252255	Trim, Side Glass Crisper	16		Screw
2	2179404	Rack, Wine	12	2256250	Trim, Side Glass Meat Pan		8533929	Screw (Stainless)
3	W10556312	Meat Pan Cover Assembly	13		Spacer, Crisper			Left Hand
4	W10556775	Crisper Cover Assembly		2256222	Right Hand		8533928	Screw (Stainless)
5	2257582	Trim, Glass (Rear)		2256223	Left Hand	17	W10407627	Pan Assembly Meat
6	W10407624	Crisper Pan	14		Slide, Crisper	18	2256366	Front, Meat Pan
7		Slide, Meat Pan		2302956	Left Hand			
	2302954	Left Hand	15	2302957	Right Hand			
	2302955	Right Hand		2256243	Left Hand			
8	2302831	Trim, Glass Front		2256244	Right Hand			
9	2256254	Trim, Glass (Rear)						
10	2256248	Front, Crisper Pan						

FREEZER SHELF PARTS




FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175905	Wire, Shelf
2	2302883	Shelf, Fixed
3	2259082	Basket, Freezer
4	2256270	Front, Basket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Slide, Basket
	2259317	Right Hand
	2259318	Left Hand
6	8533928	Screw (Stainless)


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10193490	Door Assembly, Refrigerator	12	2309060	Spacer, Handle Side Door	22	2257616	Door, Utility Bin
3	W10485980	Assembly, Top Hinge	13	488568	Screw (Stainless)	23	W10323599	Bin, Door-Shallow
4	2316804	Spacer, Door Hinge Bottom	14	8281250	Screw (Stainless)	24	W10323747	Shelf, Door (Gallon)
5	W10162602	Screw	15	2005433	Spacer, Door Skin Top	25	W10127710	Plate, Handle Door
6	2302878	Hinge Assembly, Bottom	16	308544	Screw			
7	2222796	Rail, Lid	17	W10142296	Spacer, Door			
8	2222982	Gasket, Utility Bin	18	2004934	Spacer, Door Skin Bottom			
9	2222811	Door Gasket, Magnetic	19	W10127977	Filler, Door			
10	108094	Skin, Door Stainless	20		End Cap			
11	W10168981	Mount, Handle		W10323172	Right Hand			
				W10323173	Left Hand			
			21	W10323036	Bin, Utility Center			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10292456	Freezer Door	8	2309060	Spacer, Handle Side Door	14	W10142296	Spacer, Door
2	2302879	Assembly, Bottom Hinge	9		Skin, Door	15	308544	Screw
3	W10162602	Screw		W10561670	Stainless	16		Filler, Door
4	W10485980	Assembly, Top Hinge	10	8281250	Screw (Stainless)		W10159585	Top
5	2316804	Spacer, Door Hinge Bottom	11	2005433	Spacer, Door Skin Top		W10159582	Bottom
6	2222814	Door Gasket, Magnetic	12	488568	Screw (Stainless)	18	W10323602	Bin, Shallow
7	W10168981	Mount, Handle	13	2257385	Spacer, Door-Skin (Bottom)	19	W10127710	Plate, Handle Door


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	7		Housing, Middle (Not Available Order Item 8)	11	2305219	Cover, Control
2	486194	Screw	8	W10260622	Assembly, Housing	12	2321746	Assembly, UI Control Cover
3	W10546285	Assembly, Motor & Bracket	9		Pad, Water	13	W10553816	User Interface Assembly
4	W10504458	Door, Ice		2305307GN	Universal Silver	14		Drip Tray Assembly
5	2305235	Assembly, Spigot	10		Pad, Ice		2318062US	Universal Silver
6	2318017	Assembly, Separator		2305306GN	Universal Silver	15	2305342	Assembly, LED


TOP GRILLE AND UNIT COVER PARTS



TOP GRILLE AND UNIT COVER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Decorative Assembly	4	2256466	Panel, Unit Back	8		Nameplate
	W10560589	Stainless	5	W10185625	Unit Cover, Front		W10560583	Stainless
2	W10624563	Cover, Unit	6	487415	Screw	9	489348	Clamp, Tube
3	486194	Screw	7	W10167456	Assembly, RC Wire	10	2215910	Grommet, Flexible


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10449006	Inverter Box Assembly	17	W10427091	Assembly, Unit Wire	34	W10321055	Bracket, Mounting (Power Switch)
2	489373	Screw	18	2310207	Assembly, Condenser Fan Wire	35	549193	Clamp, Power Cord
3	W10173296	Compressor	19	W10587113	Grommet	36	2266802	Switch, Power Disconnect
4	W10321056	Housing, Control Board	20	4389107	Wire Tie	37	487294	Screw
5	2318054	Control, Electronic	21	W10175593	Drier			Following Parts Not Illustrated
6	1100826	Grommet	22	W10414681	Bracket, Fan Motor (Condenser Fan)		978025	Valve, Access
7		Support, Condenser	23	2188875	Motor, Condenser		978026	Valve, Access
	W10525179	Right Hand	24	W10139483	Blade, Fan		978027	Valve, Access
	W10525177	Left Hand	25	W10415670	Orifice, Fan		978028	Valve, Access
8	W10625009	Tube, Heat Loop Transition	26	8533993	Screw		978029	Valve, Access
9	2215676	Cover, Terminal	27	2259350	Board, Power Supply		978030	Valve, Access
10	W10483905	Jumper, Inverter	28	W10356040	Control, Electronic		876764	Valve, Access
11	W10200659	Control, Electronic	29	W10624944	Tube, Drier Transition			REFRIGERANT CHARGE
12	2203075	Spacer	30	W10528578	Tube, Process			6.75 oz. (R-134A)
13	2256328	Bracket, Inverter Mounting	31	486194	Screw			
14	W10495645	Ground, Inverter	32	W10525175	Top Cover, Condenser			
15	1157158	Screw	33	2310251	Service Cord			


LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2215648	Dampener	9	W10412488	Tube, Discharge	18	2320554	Support, Drain Pan
2	486194	Screw	10	2188820	Thermistor	19	W10160981	Bracket, Air Return Assembly
3	W10157752	Bracket, Heater	11	W10427992	Evaporator	20	2169104	Sealer, Insulation
4	W10306442	Tube, Oil Trap Suction	12	W10140161	Heater, Defrost	21	304392	Screw
5	W10388653	Tube, Transition (Drier/Restrictor)	13	1113048	Clamp, Heater			
6	W10281063	Drain Pan Assembly	14	W10139908	Cover, Evaporator Seal			
7	W10309012	Cover, Wiring	15	W10432308	Gasket, Evaporator			
8	W10321048	Cover, Wire Box	16	2155774	Tie, Wire			
			17	W10169509	Clip, Heat Exchanger			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2320601	Shield, Water Valve	15	W10141604	Screw	28	W10223929	Assembly, Module
2	W10508659	Assembly, Icemaker Wire	16	W10122527	Assembly, Mold and Heater	29	489136	Screw
3	628379	Clip, Thermal Fuse	17		Motor, (Not Serviceable Order Item 28)	30	W10141645	Screw
4	W10296807	Tube, Filter Inlet	18	W10272168	Cup, Water Fill	31	486194	Screw
7	W10437853	Tube, Filter Outlet	19	627843	Ejector	32	2252228	Bracket, Icemaker Mounting
8	W10159842	Valve, Solenoid	20	W10272161	Stripper, Ice	33	304392	Screw
9	2221070	Clamp, Tube	21	2194712	Support, Housing	100	W10277448	Complete Icemaker Assembly
10	2320559	Support, Valve	22	2315522	Retainer, Thermostat			
11	2198641	Bracket, Icemaker Cover	23	W10290336	Thermostat			
12	2208136	Clip, Water Tube	24	8533917	Screw			
13	W10357286	Fitting, Water	25	W10279391	Wire Assembly, Smart Valve			
14	W10289690	Cover, Icemaker	26	489276	Screw			
			27	W10504753	Cover, Icemaker			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key