


42" BUILT IN REFRIGERATOR

MODELS:

DYF42BNDI00 (Etched Aluminum)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Top	30		Grille Bottom, Front
	W10556315	Use & Care Guide		2252292	Right Hand		2325185B	Black
	W10593345	Energy Guide		2252291	Left Hand	31	W10485630	Screw
	W10597176	Service & Wiring Sheet	16	W10348782	Bracket, Filter	32	487415	Screw
	2306424	Icemaker and Ingredient Care Center Service Sheet	17	W10001250	Screw	33	1163283	Screw
	W10565752	Installation Instructions	18	2004994	Lock, Bushing	34	2006617	Bracket, Base Support
2		Cabinet (Not Serviced)	19	W10484913	Bushing, Top Hinge	35	2215938	Cover, Switch
3	2318189	Tray, Filter Drip	20	2221242	Spring, Door Closure (Green)	36	2316859	Bushing, Extension Arm
4	W10138054	Assembly, Roller	21	3400230	Screw	37	W10167456	Assembly, RC Wire
5		Support Base Assy	22	2005008	Retaining Ring, Adjustable Bushing	38		Button, Water Filter
	W10138423	Right Hand	23	2215612	Cover, Air Duct		2260503B	Black
	W10279275	Left Hand	24	2221097	Right Hand	39	1118894	Switch, Rocker Arm (Ref)
6		Cap, Water Filter	25	2221096	Left Hand		1115373	Switch, Rocker Arm, Combination(Freezer)
	2260518B	Black			Hinge, Bottom	40	8281163	Screw (Stainless)
7	2307640	Mounting Bracket, Grill		2309472	Freezer Side	41	2004514	Clip
8	2320509	Stop, Door	26	2309471	Refrigerator Side	42		Bracket, Support Base (Front)
9	W10121140	Housing, Water Filter	27	2302876	Bushing, Adjustable		2006616	Left Hand
10	2307584	Grommet, Crossover Tube	28	8533913	Screw		2006556	Right Hand
11	3400525	Screw		2209025B	Black	43	W10141604	Screw
12	AFF6	Filter, Water	29		Extension Arm	44	2005032	Leveler, Adjustable
13	8281164	Screw (Stainless)		2267192	Right Hand			
14	2005378	Screw, Door Stop		2267193	Left Hand			


CABINET TRIM PARTS



CABINET TRIM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cab Side (Right)	4	486194	Screw	7	W10121451	Insert, Blind Threaded
	W10132411	Aluminum	5		Trim, Top Cab	8	2005925	Seal, Side Trim
2	1163283	Screw		2313961S	Aluminum	9	W10001250	Screw
3		Trim, Bottom Cab	6		Trim, Cab Side (Left)			
	2316687	Aluminum		W10132416	Aluminum			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not Serviced)	18	2309222	Assembly, Air Diffuser	30		Slider, Crisper
2	2306010	Thermistor	19	W10191429	Socket, Light		2302957	Right Hand
3	2208970	Air Duct	20	2307751	Light Shield		2302956	Left Hand
4	487539	Screw (Stainless)	21	2326255	Bulb, Light	31		Screw
5	2259077	Ladder, Shelf	22	W10539443	Control Box Assembly			Right Hand
6	520965	Support, Ladder	23	2317000	Clip, Control Box		8533929	Screw (Stainless)
7	2006475	Screw (White)	24	8281163	Screw (Stainless)			Left Hand
8	2309087	Cover, Air Diffuser	25	W10151210	Display Board, Ingredient Care Center		8533928	Screw (Stainless)
9	2302937	Thermistor Assembly	26	W10142283	Screw (White)			
10	W10475010	Assembly, Spacer	27		Spacer, Meat Pan			
11	W10169528	Assembly, Control Baffle		2256244	Right Hand			
12	W10159487	Diverter, Crisper Cover		2256243	Left Hand			
13	2188820	Thermistor	28		Slide, Meat Pan			
14	8533929	Screw (Stainless)		2302955	Right Hand			
15	486194	Screw		2302954	Left Hand			
16	2317844	Assembly, Thermistor	29		Spacer, Crisper			
17	2221296	Air Baffle Assembly		2256222	Right Hand			
				2256223	Left Hand			


FREEZER LINER AND AIR FLOW PARTS



FREEZER LINER AND AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	14	2182120	Fan Scroll	24	2259032	Ladder, Shelf
2	2266801	Air Deflector	15	2259465	Wedge, Left Air Duct	25	W10173127	Assembly, Shelf Stud
3	2169142	Blade, Fan	16	2307777	Air Duct	26	W10142283	Screw (White)
4	W10260421	Retainer, Fan Motor	17		Block, Fan Scroll	27		Evaporator, Cover Rail
5	2302817	Gasket, Cover		2209480	Right Hand		2259355	Right Hand
6	W10321090	Grommet, Motor		2209066	Left Hand		2221107	Left Hand
7	486194	Screw	18		Liner (Not Serviced)	28	2220904	Gasket, Evaporator Cover
8	2259464	Wedge, Right Air Duct	19	2259025	Cover, Air Outlet	29	2302850	Support, Air Duct
9	1112260	Support, Evaporator	20	2307751	Light Shield	30	W10482187	Harness, Bi-Metal Wire
10	W10191429	Socket, Light	21	W10428000	Cover, Evaporator	32	2188820	Thermistor
11	2155774	Tie, Wire	22	487539	Screw (Stainless)	33	2317844	Assembly, Thermistor
12	2326255	Bulb, Light	23	2309283	Deflector, Air Duct	34	2006475	Screw (White)
13	2259445	Support, Ladder Screw						

REFRIGERATOR SHELF PARTS




REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10556777	Shelf Assembly
2	2179404	Rack, Wine
3	W10556312	Meat Pan Cover Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10556775	Crisper Cover Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10407627	Pan Assembly Meat
6	W10407624	Crisper Pan


FREEZER SHELF PARTS



FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10175905	Wire, Shelf	5	2256270	Front, Basket	7	8533928	Screw (Stainless)
2	W10213534	Cover, Shelf	6		Slide, Basket	8	2266934	Door, Ice
3	2302883	Shelf, Fixed		2259317	Right Hand	9	2266931	Bucket, Ice
4	2259082	Basket, Freezer		2259318	Left Hand			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10193490	Door Assembly, Refrigerator	12		Cover, Trim	20		Bin, End Cap
2	2207457	Trim, Corner		2314003S	Aluminum		W10323172	Right Hand
3	W10484480	Hinge Assembly, Top	13	W10482554	Cover, Bottom Gap		W10323173	Left Hand
4	2316804	Spacer, Door Hinge Bottom	14	W10323747	Shelf, Door (Gallon)	21	W10323036	Bin, Utility Center
5	W10162602	Screw	15	8281250	Screw (Stainless)	22	2257616	Door, Utility Bin
6	2252293	Assembly, Bottom Hinge	16		Trim, Door Top	23	W10323599	Bin, Door-Shallow
7	2222796	Rail, Lid		2309486S	Aluminum			
8	2222982	Gasket, Utility Bin	17		Trim, Screw Cover			
9	2222811	Door Gasket, Magnetic		2259448S	Aluminum			
10	2006346	Washer, Extension Arm	18		Trim, Door Hinge Side			
11		Trim, Door Handle Side		2309498S	Aluminum			
	2309497S	Aluminum	19		Trim, Door Bottom			
				2309492S	Aluminum			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10193486	Freezer Door, Service	9		Trim, Door Handle Side	14		Trim, Door Hinge Side
2	2207457	Trim, Corner		2309497S	Aluminum		2309498S	Aluminum
3	2252294	Hinge, Bottom	10		Trim, Screw Cover	15	W10323602	Bin, Shallow
4	W10162602	Screw		2259448S	Aluminum	16	2006346	Washer, Extension Arm
5	W10484480	Hinge Assembly, Top	11	8281250	Screw (Stainless)	17	W10482554	Cover, Bottom Gap
6	2316804	Spacer, Door Hinge Bottom	12		Trim, Door Top			
7	2222814	Door Gasket, Magnetic		2309489S	Aluminum			
8		Cover, Trim	13		Trim, Door Bottom			
	2314003S	Aluminum		2309495S	Aluminum			

TOP GRILLE AND UNIT COVER PARTS




TOP GRILLE AND UNIT COVER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Grille Assembly
	2313978S	Aluminum

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10188580	Cover, Unit
3	1157158	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	2256466	Panel, Unit Back
5	W10185625	Unit Cover, Front


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10449006	Inverter Box Assembly	18	2310207	Assembly, Condenser Fan Wire	37	2266802	Switch, Power Disconnect
2	489373	Screw	19	489399	Screw	38	W10483905	Jumper, Inverter
3	W10173296	Compressor	20	2155774	Tie, Wire	39	W10495645	Ground, Inverter
4	W10321056	Housing, Control Board	21	W10175593	Drier	40	W10234131	Tube, Heat Loop Transition Following Parts Not Illustrated
5	2309432	Gasket, Condenser	22	W10414681	Bracket, Fan Motor (Condenser Fan)		978025	Valve, Access
6	1100826	Grommet	23	2188875	Motor, Condenser		978026	Valve, Access
7		Support, Condenser	24	W10139483	Blade, Fan		978027	Valve, Access
	W10415668	Right Hand	25	W10415670	Orifice, Fan		978028	Valve, Access
	W10415666	Left Hand	26	487294	Screw		978029	Valve, Access
8	2259350	Board, Power Supply	27	8533993	Screw		978030	Valve, Access
9	2215676	Cover, Terminal	28	2317031	Assembly, Bracket		876764	Valve, Access
11	W10200659	Control, Electronic	29	2317030	Assembly, Arm			REFRIGERANT CHARGE
12	2203075	Spacer	30	2307566	Tube, Drier Transition			7.50 oz. (R-134A)
13	2256328	Bracket, Inverter Mounting	31	2194319	Tube, Process			
14	W10356040	Control, Electronic	32	486194	Screw			
15	1157158	Screw	33	2309000	Cover, Condenser			
16	2307998	Condenser	34	2310251	Service Cord			
17	W10427089	Wire Assembly, Unit	35	W10321055	Bracket, Mounting (Power Switch)			
			36	549193	Clamp, Power Cord			

LOWER UNIT AND TUBE PARTS




LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10160981	Bracket, Air Return Assembly
2	W10388653	Tube, Connect Drier Restrictor
3	486194	Screw
4	W10157752	Bracket, Heater
5	W10306442	Tube, Oil Trap Suction
6	W10281063	Drain Pan Assembly
7	W10316077	Cover, Bottom Wiring

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10321048	Cover, Wire Box
9	W10412488	Tube, Discharge
10	W10321050	Shelf, Wiring Cover
11	W10427992	Evaporator
12	W10140161	Heater, Defrost
13	1113048	Clamp, Heater
14	W10413009	Grommet Air Return
15	W10139908	Cover, Evap Seal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10432308	Gasket, Evaporator
17	2155774	Tie, Wire
18	W10169509	Clip, Heat Exchanger
19	2320554	Support, Drain Pan
20	2215648	Dampener
21	304392	Screw

ICE MAKER PARTS



ICE MAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	486194	Screw	14	W10001250	Screw	28	8533917	Screw
2	2221240	Heater, Fill Tube	15	2208136	Clip, Water Tube	29	2320559	Support, Valve
3	489136	Screw	16	W10129069	Clip, Tube	30	489276	Screw
4	W10482373	Wire Assembly, Fill Tube Heater	17	W10508673	Wire Assembly, Ice Maker	31	2304354	Arm, Shut Off
5	628379	Clip, Thermal Fuse	18	W10289690	Cover, Icemaker	32	626691	Assembly, Module & Motor
6	W10296807	Tube, Filter Inlet	19	W10279393	Wire Assembly (Water Valve)	33	2259064	Cover, Fill Tube Heater
7	2314049	Water Inlet Tube Assembly	20	W10122527	Mold & Heater Assembly	34	2221070	Clamp, Tube
8	1106508	Gasket, Seal	21		Motor (Not Available, Order #32)	100	W10277450	Complete Icemaker Assembly
9	W10437853	Tube, Filter Outlet	22	W10435665	Cup, Water Fill			
10	2307650	Valve, Solenoid	23	627843	Ejector			
11	W10129653	Shield, Valve Electrical	24	W10122563	Stripper, Ice			
12	487294	Screw	25	2194712	Support, Housing			
13	2221231	Shield, Heat	26	2315522	Retainer, Thermostat			
			27	627985	Thermostat			