



The Life of the Kitchen.®

PARTS CATALOG

GC30, GC36, GC46 Cooktop

IMPORTANT: This appliance may have some parts that are **No Longer Available (NLA)**. If the part you need is no longer available, please contact Dacor for a possible solution.

DACOR CARES PROGRAM NLA Part Locator Service

Customer Contact Number:

(800) 793-0093 ex. 2813
Hours: 6:00 AM - 5:00 PM Pacific Time

Service Agent/Technician Contact Number:

(800) 793-0093 ex. 3814
Hours: 7:00 AM - 4:00 PM Pacific Time

Web Inquiries: www.dacor.com/dacorcares

Email Inquiries: dacorcares@dacor.com


Please provide the following information:

- Your name and phone number
- Product serial number
- Product model number
- The part number(s) you need

Page	Description
2	GC30/36 Assembly
3	GC30/36 Parts
4	GC46 Assembly
5	GC46 Parts

Revised 02-28-2012

GC30, GC36 Cooktop Assembly




GC30, GC36 Cooktop Parts

Item	Part #	Description
1	82458BP	GAS BURNER GRATES
2	82529	GAS CONTROL PANELS
3	82530	GAS KNOB
4	26166BP	GAS DRIP TRAY
5	26206B,W,S	GAS TOP FRAME 36"
6	26218B,W,S	GAS TOP FRAME 30"
7	82486	SPARK SWITCH
8	82527	MANIFOLD PIPE
9	82515BP	GC BURNER CAP
10	82526	TOP BURNER REAR
11	82525	TOP BURNER FRONT
12	82539	ELECTRODE CAP
13	82537	ELECTRODE ASSY RH 36"
14	82545	ELECTRODE ASSY LH 30"
15	26208	GC BURNER SUPPORT BRKT
16	82545	ELECTRODE ASSY LH 36"
17	82537	ELECTRODE ASSY RH 30"
18	12045	TOP BRACKET
19	12045	TOP BRACKET
20	26219	HEAT SHIELD
21	82536	REGULATOR
22	12129	GAS SUPPLY CORD
23	27250	GC 30" GAS CHASSIS
24	27224	GC 36" GAS CHASSIS
25	26207	MANIFOLD MTG CHANNEL
26	82571	GAS TUBING ASSY LF 30"
27	82567	GAS TUBING LF 36"
28	82487	SPARK MODULE
29	82572	GAS TUBING ASSY LR 30"
30	82568	GAS TUBING ASSY LR 36"
31	82569	GAS TUBING ASSY RF 30"
32	82565	GAS TUBING ASSY RF 36"
33	82570	GAS TUBING ASSY RR 30"
34	82566	GAS TUBING ASSY 36"
35	82478	BURNER VALVE
-	12130	WIRE HARNESS (not shown)

Part no longer available? Call Dacor: (800) 793-0093 ex. 3814

GC46 Cooktop Assembly



GC46 Cooktop Parts

Item	Part #	Description
1	82530	GAS KNOB
2	82542	GAS CONTROL PANELS
3	82458BP	GAS BURNER GRATES
4	26166BP	GAS DRIP TRAY
5	26301A,B,S,W	GAS TOP FRAME 46"
6	82486	SPARK SWITCH
7	82590	MANIFOLD PIPE
8	82478	BURNER VALVE
9	83251	BURNER VALVE SCREW
10	82515BP	GC BURNER CAP
11	82526	TOP BURNER REAR
12	82525	TOP BURNER FRONT
13	82594	LEFT REAR TUBING
14	82593	LEFT FRONT TUBING
15	82596	CENTER REAR TUBING
16	82595	CENTER FRONT TUBING
17	82598	RIGHT REAR TUBING
18	82597	RIGHT FRONT TUBING
19	26208	BURNER SUPPORT BRACKET
20	82537	RIGHT ELECTRODE LEAD
21	82545	CENTER ELECTRODE LEAD
22	82592	LEFT ELECTRODE LEAD
23	12187	CHASSIS
24	26299	MANIFOLD MOUNTING CHANNEL
25	86059	SPARK MODULE
26	26298	SPARK MODULE ANGLE
27	12179	SUPPLY CORD
28	82539	ELECTRODE CAP
29	27251	COOKTOP HOLD DOWN BRACKET
30	83248	1/4-20 x 3 RD HD SLOT
-	12180	WIRE HARNESS (not shown)

Part no longer available? Call Dacor: (800) 793-0093 ex. 3814