

dacor®

The Life of the Kitchen.®

PARTS CATALOG


RO230/ROV230 Wall Oven

Page #	Description
2	Door Assembly
3	Door Parts
4	Chassis Assembly - Front
5	Chassis Parts - Front
6	Chassis Assembly - Rear
7	Control Panel
8	Sub-Chassis Electrical Components
9	Oven Cell Components
10	Miscellaneous Components

Revised 04-09-2015

RO230/ROV230 Wall Oven Door Assembly

External handle version shown.



RO230/ROV230 Wall Oven Door Parts

Complete Door Assemblies

Part #	Description
701475-01	COMPLETE TOP DOOR ASSEMBLY, RO230B
701475-02	COMPLETE BOTTOM DOOR ASSEMBLY, RO230B
701698-03	COMPLETE TOP DOOR ASSEMBLY, RO230FS
701698-04	COMPLETE BOTTOM DOOR ASSEMBLY, RO230FS
701426-01	COMPLETE TOP DOOR ASSEMBLY, RO230S
701426-02	COMPLETE BOTTOM DOOR ASSEMBLY, RO230S
701788-01	COMPLETE TOP DOOR ASSEMBLY, RO230W
701788-02	COMPLETE BOTTOM DOOR ASSEMBLY, RO230W
701503-01	COMPLETE TOP DOOR ASSEMBLY, ROV230B
701503-02	COMPLETE BOTTOM DOOR ASSEMBLY, ROV230B

Door Components

Item	Part #	Description
1	701474	ASSEMBLY, DOOR SKIN, RO130B
	701697	ASSEMBLY, DOOR SKIN, RO130FS
	701427-01	ASSEMBLY, DOOR SKIN, RO130S
	701789	ASSEMBLY, DOOR SKIN, RO130W
	701759	ASSEMBLY, DOOR SKIN, ROV130B
2	13659-001	ASSEMBLY, DOOR HANDLE, STAINLESS
	13659-019	ASSEMBLY, DOOR HANDLE, BLACK
	13659-021	ASSEMBLY, DOOR HANDLE, WHITE
3	72510CH ¹	LOGO, DACOR, 3", CHROME ¹
4	107221B	HEAT SHIELD
5	105353	INSULATION, SIDE DOOR
6	105352	INSULATION, TOP DOOR
7	72711	HINGE, LEFT
8	72710	HINGE, RIGHT


Item	Part #	Description
9	72968	WINDOW PACK
10	100015	GASKET, WINDOW PACK
11	701428-01 ²	ASSEMBLY, DOOR LINER, RO130S
	701428-02 ²	ASSEMBLY, DOOR LINER, RO130B, RO130W, ROV130B
	701428-05 ²	ASSEMBLY, DOOR LINER, RO130FS
12	701430BP ³	DOOR LINER ³
13	100026	SCREW, #10-32 X 2.0, TORX
14	105510-01	HINGE BRACKET COVER, RIGHT
15	105510-02	HINGE BRACKET COVER, LEFT
16	83263	SCREW, PHIL TRS, #8 X 3/8, BLACK

² Pre-assembled, includes door liner, window pack w/ gasket, hinges, hinge covers, all insulation, heat shields, air deflectors.

³ Door liner alone.

¹ For use on upper door only.

RO230/ROV230 Wall Oven Chassis Assembly - Front



RO230/ROV230 Wall Oven Chassis Parts - Front


Item	Part #	Description
1	-	SUB-CHASSIS ¹
2	105324	COVER, TOP
3	105320	COVER, COOLING FAN
4	105363	EMBOSS, COOLING FAN
5	105318	TOP RIGHT REAR CORNER
6	105314	TOP, RIGHT SIDE
7	105462	HEAT SHIELD, DUCT
8	105389-01B	TRIM POST, RIGHT
9	83709	SCREW, #8 X 1/2", TORX, BLK
10	105463	HEAT SHIELD, LOWER DUCT
11	83710	SCREW, WASHER HD #8 X 3/8
12	701423	ASSEMBLY, EXHAUST PLATE
13	83263	SCREW, PHIL TRS, #8 X 3/8, BLK

¹ See page 7 for individual components

Item	Part #	Description
14	105350B	EXHAUST GRILL (BLACK)
	105350W	EXHAUST GRILL (WHITE)
	107735	EXHAUST GRILL (STAINLESS)
15	105405B	INTAKE GRILL, LOWER OVEN
16 ²	-	ASSY, BEZEL/CAPACITIVE TOUCH ²
17	105357B	INTAKE GRILL, TOP
18	105388	SUPPORT, DOUBLE OVEN
19	105389-02B	TRIM POST, LEFT
20	100090	LATCH, WALL OVEN
21	105315	TOP, LEFT SIDE
22	105319	TOP, FRONT SUPPORT
23	105323	COVER, LATCH
24	92321	HIGH LIMIT SWITCH
25	105366	DOOR GASKET
26	105468BP	DOOR GASKET COVER

² See page 6 for individual components

RO230/ROV230 Wall Oven Chassis Assembly - Rear




See page 7 for wiring harness.

Item	Part #	Description
1	105330	DUCT, SMOKE ELIMINATOR
2	105478	COVER, MEAT PROBE WIRE
3	105326	DUCT, REAR
4	105387	COVER, DOUBLE OVEN
5	82347	FAN, COOLING
6	83055	SNAP BUSHING
7	105484	BAKE ELEMENT, CORNER
8	105386	COVER, LOWER COOLING FAN

Item	Part #	Description
9	105358	COVER, BACK DOUBLE OVEN
10	83133	BUSHING, 1/2", RED
11	26420	CONDUIT, 1/2" FLEX, CUT 60
12	82195	1/2" 90° SQUEEZE CONNECTOR
13	92191-02	BUSHING, SPLIT 1.0"
14	92191-03	BUSHING, SPLIT 1.375"
15	105316	TOP REAR


RO230/ROV230 Wall Oven Control Panel Assembly



Item		Description
1	701476-02*	ASSEMBLY, BEZEL/CAPACITIVE TOUCH, RO230B
	701431-02*	ASSEMBLY, BEZEL/CAPACITIVE TOUCH, RO230S
	701504-02*	ASSEMBLY, BEZEL/CAPACITIVE TOUCH, ROV230B
2	105336	CONTROL BOARD, RO230/ROV230
3	105334	CONTROL BOARD BASE
4	105486	SCREW, 6-19 X 3/8"
5	105655	RIBBON CABLE


* Includes items 2, 3 and 4 (6 each).

RO230/ROV230 Sub-Chassis Electrical Components



Item	Part #	Description
1	102380	RELAY BOARD, RO230/ROV2330
2	105448	WIRING HARNESS, POWER BOARD
3	83538	PCB SUPPORT, NYLON
4	100832	TRANSFORMER, RO230/ROV230
5	83023	SCREW, SLOT HWH #10 X 3/8 THD
6	105413	WIRING HARNESS, MAIN
7	83009	NUT, KEPS, #10-24
8	92191-02	BUSHING, SPLIT 1.0"
-	105729	WIRING HARNESS EXTENSION RELAY BOARD/TOUCH PAN (not shown)

RO230/ROV230 Wall Oven Cell Components



Item	Part #	Description
1	106898	BAKE ELEMENT
2	82377	CONVECTION ELEMENT
3	105329BP	CONVECTION BAFFLE
4	701529 ¹	BROIL ASSEMBLY ¹
5	72752	SENSOR, TEMPERATURE
6	92398	ASSEMBLY, HALOGEN LIGHT, 12V, 20W
7	100429	BULB, HALOGEN, 12V, 20W
8	72755	SMOKE ELIMINATOR
9	72348	HINGE RECEPTACLE
10	106991	RACK SUPPORT

¹ Broil assembly includes element, glass and frame.


Item	Part #	Description
11	700633 ²	KIT, CONVECTION FAN ²
12	82891	FILTER, CONVECTION
13	101511	CONVECTION FAN BLADE
14	83708	SCREW, TORX WAFER HEAD, #8 X 1/2"
15	72717 ³	MEAT PROBE SOCKET ³
16	102137	HEX NUT, CONVECTION FAN
17	102136	WASHER, CONVECTION FAN
18	83661	SCREW, WASHER HEAD #8 X 3/8
19	83379	SCREW, #8-1/2 THREAD TYPE A
20	102468 ⁴	PLUG, PROBE, OVEN CELL ⁴

² Kit includes motor, fan blade, fan blade washer and mounting nut.

³ Used on upper oven only.

⁴ Used on lower oven only.

RO230/ROV230 Wall Oven Miscellaneous Parts



Item	Part #	Description
1	701464	OVEN RACK, GLIDERACK TYPE
2	100429	BULB, HALOGEN, 12V, 20W
3	92398	ASSEMBLY, LIGHT, HALOGEN, 12V, 20W
4	72723	MEAT PROBE
5	100852	STAINLESS STEEL CLEANER
6	106992	OVEN RACK, STANDARD
7	82106	PORCELAIN GRILL
8	82107	PORCELAIN PAN